



Step 1

Using the remote, move the shade to the Down position. If the shade's batteries are completely depleted, you may skip to step 3.




Step 2

Tug the shade past the Down position. The shade will then automatically reverse direction and move to the 75% position.



Step 3

Carefully pull the hembar (D) down in one continuous motion until the battery window is exposed. Ensure Manual Operation is deactivated by tugging the shade or turning the tube. If deactivated, remove the battery cover to expose battery access.



Step 4

Replace all batteries with fresh D-Cell alkaline batteries. Always use the same brand and manufacturing date. Orient all batteries with the positive end as shown.



Step 5

Reinstall the battery cover flush with the shade tube. Press any button. The shade moves to the Up position. The shade will now resume normal operation. All positions are recovered from memory.